XG Assembly Tooling and Accessories

# Tooling


# ■ XG4 / XG2 - Flat Cable Sockets and Bus Connectors

#### IDC Press

XY2B-0002


XY2B-1004

XY2B-0002 IDC Press Tool (Attachments sold separately)



### IDC Press Attachments for terminating XG4M and XG2A

#### XY2B-1006 XY2B-1007 Operation Base attachment for the XG2A Base attachment for the XG4M XG4M-series Connectors must be placed face down Locator groove into the locator slot of the Attachment. (With the XG2A Cable stopper Series, place the terminal block in the Attachment.) Insert the cable until it is flush against the cable stopper. Connections are made by pulling the handle towards you until it stops. For details on operation, see the user's manual supplied with the IDC Tool. **IDC Press Base Attachment** Applicable Socket Note: An additional head attachment or spacer is not XY2B-1007 XG4M (All contacts) needed to terminate the XG4M and XG2A XY2B-0002 XY2B-1006 XG2A (All contacts) connectors. IDC Press Attachments for XG4E XY2B-1004 XY2B-14 Operation Base attachment for the XG4E Spacer for the XG4E (See below) XG4E-series Connectors must be placed face down into the locator slot of the Attachment. Insert the cable until it is flush against the cable stopper. Next set the proper spacer for the Plug. Connections are made by pulling the handle **IDC Tool Base Attachment** Spacer Applicable Plug towards you until it stops. XG4E-10 1/-10 2 XY2B-1401 XG4E-1431/-1432 XG4E-1631/-1632 XY2B-1402 XG4E-2031/-2032 XG4E-2631/-2632



# ■XG5 - Discrete Wire Sockets


#### **Manual IDC Termination Tool**

XY2B-7006




### **Automated Wire IDC Tool Set**

XY2B-2104-N



## Contact Removal Tool

XY2E-0001



Used to remove contacts, which need to be replaced or reconfigured, from the housing.

# This tool is a compact, light-weight model, ideal for use in the laboratory or for maintenance.

#### Specifications

Applicable connector	XG5M-N		
Applicable wire	AWG24 to AWG28 (with an insulation outer diameter of 1.1 to 1.3 mm)		
Dimensions	25 (W) × 100 (L) × 80 (H)		
Weight	Approx. 180 g		

This Wire IDC Tool Set is designed for XG5 Discrete-wire Connectors.

#### Specifications


Stroke	13 mm			
Motor speed	83/100 rpm (50/60 Hz)			
Feed pitch	2.54 mm			
Operation	Foot switch			
Weight	About 6 kg			
Rated voltage	0.5 A, 100 VAC (50/60 Hz)			
Fuse	1 A			
Dimensions	$120\times200\times225$ mm (W $\times$ H $\times$ D)			

Note: For function and operation details, see the user's manual for the Pressure Welder provided separately.

### **Replacing Contacts**

Use only this tool to remove incorrect IDC contacts.

- 1. Remove the cover.
- 2. Insert the tool into the housing lance holes and push the lance into the housing.
- 3. Pull out the contact while holding the lance down.
- 4. Insert a new contact.



#### **Applicable Connectors and Wires**

		Applicable wires			
Applicable Connector	Size No.	UL file No.	Size [No. of wires/diameter] (mm)]	Cross-sectional area (mm)	Covering diameter (mm)
XG5M-□□31-N XG5M-□□32-N XG5M-□□33-N	No. 1	UL1061	AWG24 [7/0.203]	0.21	1.10
XG5M-034-N			AWG26 [7/0.16]	0.13	1.30
XG5M-□□35-N XG5M-□□36-N	No. 2	UL1007	AWG28 [7/0.127]	0.09	1.22

Note: Use only wires specified in the table above

# Accessories - XG4 / XG5 / XG8

### External Polarization Options

The following optional accessories can be used to provide polarization to sockets and plugs that do not have molded polarizing guides and slots built into their housings and shrouds.


### Solutions for Shrouded Connectors

#### XG4Z-0004 Polarizing Key

Typically, 10 contact versions of the XG4A, XG4E and XG4C are available with or without polarizing guides.

Install the XG4Z-0004 polarizing key on XG4A pcb sockets, XG4E plugs and XG4C pcb sockets that do not have a polarizing slot, to prevent reverse connection with XG4M cable sockets that do not have a polarizing guide.

For all other versions, the molded polarity guides and slots can be used by themselves to help prevent reverse insertion. However, use the polarizing key with these versions as well for best results.




Note: Each XG4Z-0004 has 4 Polarizing Keys.

### **Solutions for Unshrouded Connectors**

Use the XG4Z-0005 coding pin to fill a specific hole in one of the XG4 or XG5 sockets. Then, use the XY2E-0002 cutting pin to remove the corresponding terminal from an XG8 unshrouded plug. (See XG5 and XG8 datasheets for details about those connectors.)


#### XG4Z-0005 Coding Pin



Note: 1. A contact with a Coding Pin inserted cannot be used.2. Each XG4Z-0005 has 4 Polarizing Keys.


#### XY2E-0002 Contact Cutting Driver

The Contact Cutting Driver is used to cut (twist off) a contact on the mating Plug when using an XG4Z-0005 Coding Pin.




### ■ Top Lock Levers XG5Z-0002 - "Lock Lever"

Use to lock right angle XG8B and XG8W Plugs to mating sockets



XG4Z-0002 - "Lock Lever II" Use to lock XG4C Box-type Plugs to mating sockets.





■ XG5 - Spare Contacts

XG5W-0031-N (Size #1)	Size no.	Model	Order in Multples of	I
XG5W-0034-N (Size #2)		XG5W-0031-N	100	Ī
		XG5W-0034-N		
2.1		<ul> <li>Note: 1. These Contacts can be used as replacements if a wrong connection is made.</li> <li>2. The applicable wire for size No. 1 is AWG24 (UL-1061). The applicable wire for size No. 2 is AWG26 to AWG28 (UL-1007).</li> </ul>		

All sales are subject to Omron Electronic Components LLC standard terms and conditions of sale, which can be found at http://www.components.omron.com/components/web/webfiles.nsf/sales\_terms.html

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.



55 E. Commerce Drive, Suite E Schaumburg, IL 60173 **OMRON ON-LINE** 

Global - http://www.omron.com USA - http://www.components.omron.com

#### 847-882-2288

Cat. No. X304-E-1

11/10

Specifications subject to change without notice

Printed in USA

### XG Assembly Tooling and Accessories